

Protective curtain: installation (with Hollow Set Anchors)

Firstly: One hollow set anchor must be installed at a minimum of 7'1" from the floor and 2" outside of your wall extremity.

- 1) Screw one eyebolt into the hollow set anchor at 45 degrees toward the center of the wall.
- 2) Insert one quick link #1 (small) into the grommets located at each top corner of the curtain. Quick links #2 (bigger) go through the quick links #1.
- 3) Put a quick link #2 over the top corner eyebolt. Hold the curtain against the wall and mark the other top corner anchor. The mark should be made at the end of quick link #2 and 7'1" from the floor.
- 4) Install the 2nd anchor and screw an eyebolt. The position of the eyebolt head is 45 degrees toward the center of the wall. Put the canvas in place with the quick links passing over the eyebolts.
- 5) Repeat the same operation for the two lower corner anchors. The lower anchors are aligned with the top anchors. At this stage, the curtain is anchored at all four corners and the 4 eyebolts are inclined at 45 degrees toward the center of the curtain.
- 6) Install half of the remaining anchors at 7'2" (higher than the corner anchors). Put them equally between the 2 corners and **in line with a grommet**. You may have a small difference between each anchor, but that's OK.
- 7) Put the eyebolts in the anchors and quick links on the grommets in line with the top anchors. Hang the curtain on the eyebolts.
- 8) Put the quick links in the lower grommets in line with the top ones and mark the places to put the remaining anchors at the bottom of the curtain. Put in the anchors and the eyebolts. Fix the quick links over the eyebolts and your curtain is installed.
To lock the curtain, tack the steel cable through all the eyebolts around the curtain and put the padlock through one eyebolt plus the two ends of the steel cable.

Any questions?

1 800 465-2123 or climbing@passemontagne.com

